


DB9 (EXT I/O)

This is the pinout for the DB9 connector



- When the joystick top button or the "Prev" button is pressed, a relay is shorting pin 1 and 2
- If pin 8 is shorted to GND (pin 5 or 9) the Tally bar will light red and tally on the camera is activated



TALLY

PIN 2-3

PREVIEW

PIN 2-3